

Setting Up the MCR 9 RDO for 1X Drivetrains (The Clean Way)

The MCR 9 RDO utilizes a braze-on type front derailleur mount which is fixed in place by the upper shock bolt (pic below).



If you plan to build your MCR 9 RDO with single chainring drivetrain (1X), please read on. In the small parts bag included with the frame, you will find a 3MM spacer.



For a clean 1X setup, we suggest to remove the front derailleur braze-on mount from under the upper shock bolt and replace it with this spacer. **The upper shock bolt should always be installed with either the front derailleur braze-on mount or the 3MM spacer under the bolt head.**

